

Installation Instructions

Eibach Springs, Inc. • 264 Mariah Circle • Corona, California 92879-1751 • USA • Tech Support 800-222-8811 Ext 114




PRO-KIT- # 3837.140

Chevrolet Impala SS 1994-1996

Kit Contents	Description	Part Number	Qty
	Front Spring	3832.001	2
	Rear Spring	3837.002	2
	Information Kit	EPAK	1
	Instructions	3837.140INST	1

NOTES: Read All Instructions Before Beginning Installation

- Installation of a **PRO-KIT** Spring set should only be performed by a qualified mechanic experienced in the installation and removal of suspension springs.
- Use of a hoist is highly recommended and will substantially reduce installation time.
- **Never work on or under a vehicle unless it is properly supported by safety stands and wheels are blocked.**
- **PRO-KIT** Springs are marked with the letter 001 and 002 (located at the end of the part number) designating front and rear springs.
- **PRO-KIT** Springs should be installed with the **Eibach** Logo right side up. All original stock spring isolators dampers and tubing should be retained from the stock springs and used when installing the **PRO-KIT** Springs.
- **After** installation, it is always important to inspect and adjust the following if necessary:
 - Wheel alignment such as camber, caster & toe
 - Tire and/or wheel fender clearance
 - Brake line clearance and attachments
 - Brake anti-locking and anti-skid system sensors
- **Tire Rotation:** In order to increase the life of your tires, it is recommended to rotate your tires every 3,000 miles.



- It is necessary to trim the factory installed bump stops located on the front of the lower control arms. This bump stop limits suspension travel and needs to be trimmed.
- As directed in the illustration, measure 20 mm from the top (peak) of the stop and cut diagonally as shown above.