

# Installation Instructions

Eibach Springs, Inc. • 264 Mariah Circle • Corona, California 92879-1751 • USA • Tech Support 800-222-8811 Ext 114



## Anti-Roll-Kit # 5536.312

Mazda, MX5 2006

Kit Contents	Description	Part Number	Qty
	Rear Bar	5536.320R	1
	Anti-Roll Hardware Kit	5536.312HK	1
	Rear bushing	UB0001	2
	Information Kit	EPAK	1
	Instructions	5536.312INST	1

### NOTES: Read All Instructions Before Beginning Installation

- Only qualified mechanics experienced in the installation and removal of suspension components should perform this installation.
- Use of a hoist and screw jack is highly recommended and will substantially reduce installation time.
- **Installation time:** Is approximate .5 hour with the use of a hoist.
- **Never work on or under a vehicle unless it is properly supported.**
- **Tire Rotation:** In order to increase the life of your tires, it is recommended to rotate your tires every 3,000 miles.

### Additional Eibach Components Available For Your Car

Eibach Kits	Part Number	Description	Front	Rear
<i>Pro-Kit</i>	5536.140	High Performance Handling	1.0 In.	1.0 In.
<i>Sportline</i>	4.3655	High Performance Handling	2.0 In.	2.0 In.

#### FACTORY REAR BAR REMOVAL

1. Locate the OE end links (See photo 6). Remove the 14mm nuts fastening the OE Anti-Roll bar to the OE end links on both sides.



Photo 6.

2. Locate the Anti-Roll bar bushing brackets. (See photo 7.) Remove the four 14mm nuts fastening these brackets to the sub frame.




Photo 7

3. You can now remove the OE Anti-Roll bar.

### **EIBACH REAR BAR INSTALLATION**

4. Apply the supplied lubricant to the inside of the Eibach replacement bushings (Part # UB0001). Install the bushings on the Eibach bar with the “cut” portion toward the rear of the vehicle.
5. Install your new Eibach Anti-Roll bar in the reverse order of the removal.