

Installation Instructions

Eibach Springs, Inc. • 264 Mariah Circle • Corona, California 92879-1751 • USA • Tech Support 800-222-8811 Ext 114



Sportline # 4.12535

2011-13 Ford Mustang, Mustang GT, Coupe and Convertible, 3.7L V6, 5.0L V8
2012-13 Ford Mustang Boss 302, 5.0L V8, Incl. Laguna Seca


Kit Contents	Description	Part Number	Qty
	Front Spring	4.12535F	2
	Rear Spring	4.12535R	2
	Rear Bump Stop	BS45001617	2
	Information Kit	EPAK	1
	Instructions	4.12535INST	1

NOTES: Read All Instructions Before Beginning Installation

- **Only qualified mechanics experienced in the installation and removal of suspension components should perform this installation.**
- **Use** of a hoist is highly recommended and will substantially reduce installation time.
- **Never work on or under a vehicle unless it is properly supported by safety stands and wheels are blocked.**
- **Sportline** springs are marked with a F, for Front and R, for the Rear.
- **Sportline** springs should be installed with the Eibach Logo right side up. All original stock spring isolators, dampers and tubing should be retained from the stock springs and used when installing the **Sportline** Springs.
- **After** installation, it is always important to inspect and adjust the following if necessary:
 - Wheel alignment such as camber, caster & toe
 - Tire and/or wheel fender clearance, when aftermarket tires and wheels are used.
 - Brake line clearance and attachments
 - Brake anti-locking and anti-skid system sensors
- **Tire Rotation:** In order to increase the life of your tires, it is recommended to rotate your tires every 3,000 miles.
- **For MacPherson Strut type front suspension,** it is important to mark the orientation of the upper perch with respect to the lower perch before disassembly. This orientation must remain the same with the installation of the Pro Kit springs. Noise may result if this procedure is not performed correctly.

Bump Stop Modification Instructions

Typical Bump-Stop
(Bump-Stop from your vehicle may have different shape)



Rear Bump Instructions



Photo 1

1. Remove the OE bump stop assembly which is secure by two screws as shown. **(See Photo 1)**



Photo 2

2. Place the assembly in a vice, then, pulling firmly on the bump stop remove it from the bracket. **(See Photo 2)**



Photo 3

3. Insert the new Eibach bump stop into the bracket as shown. **(See Photo 3)**



Photo 4

4. Reinstall the bump stop assembly into the vehicle and secure it with the OE screws as shown. **(See Photo 4)**