Installation Instructions

Eibach Springs, Inc. • 264 Mariah Circle • Corona, California 92879-1751 • USA • Tech Support 800-222-8811 Ext 114



ProKit-# 7219.140

2006 Porsche Cayman S (Incl. PASM)

Kit Contents	Description	Part Number	Qty	
	Front Spring	7212.001VA	2	
	Rear Spring	11-72-008-01-HA	2	
	Information Kit	EPAK	1	
	Instructions	7219.140INST	1	

NOTES: Read All Instructions Before Beginning Installation

- Installation of a *ProKit* Spring set should only be performed by a qualified mechanic experienced in the installation and removal of suspension springs.
- Use of a hoist is highly recommended and will substantially reduce installation time.
- · Never work on or under a vehicle unless it is properly supported by safety stands and wheels are blocked.
- **ProKit** Springs are marked with an **VA** and an **HA** (located at the end of the part number) designating front and rear springs.
- **ProKit** Springs should be installed with the **Eibach** Logo right side up. All original stock spring isolators, dampers and tubing should be retained from the stock springs and used when installing the **SPORTLINE** Springs.
- After installation, it is always important to inspect and adjust the following if necessary:
 - Wheel alignment such as camber, caster & toe.
 - Tire and/or wheel fender clearance.
 - Brake line clearance and attachments.
 - Brake anti-locking and anti-skid system sensors.
- Tire Rotation: In order to increase the life of your tires, it is recommended to rotate your tires every 3,000 miles.

ALIGNMENT: After installation, it will be necessary to perform a full vehicle alignment using factory specifications.

Note: During installation of the Eibach rear springs it is <u>extremely important</u> that all bushing related pivot points be retorqued with the full weight of the vehicle on the suspension, this is done to prevent "bushing pre-load". This is easiest with the vehicle on a drive on type of hoist. If this is not done, bushing damage and un-even lowering may result.

