

# Installation Instructions

Eibach Springs, Inc. • 264 Mariah Circle • Corona, California 92879-1751 • USA • Tech Support 800-222-8811 Ext 114



## Anti-Roll-Kit # 7710.310

Subaru, WRX Sedan (Excluding Wagon), 2001 - 2003

Kit Contents	Description	Part Number	Qty
	Front Bar	7714.320F	1
	Anti-Roll Hardware Kit	7710.310HK	1
	Information Kit	EPAK	1
	Instructions	7710.310INST	1

### NOTES: Read All Instructions Before Beginning Installation

- Only qualified mechanics experienced in the installation and removal of suspension components should perform this installation.
- Use of a hoist and screw jack is highly recommended and will substantially reduce installation time.
- Installation time: Is approximate 2 hours with the use of a hoist.
- Never work on or under a vehicle unless it is properly supported.
- Tire Rotation: In order to increase the life of your tires, it is recommended to rotate your tires every 3,000 miles.

### Additional Eibach Components Available For Your Car

Eibach Kits	Part Number	Description	Front	Rear
Pro- Kit	7710.140	High Performance Handling	1.3 In.	1.0 In.

#### FACTORY FRONT BAR REMOVAL

1. With the vehicle safely supported, remove all 4 wheels.
2. You will need to remove the plastic under body splash shield.
3. Remove the lower sub frame from the car.  
**(Note: Two of the bolts are hidden under plastic shields.)**



4. Remove the small belly plate directly below the center of the bar.



5. Disconnect the front end links from the sway bar and from the lower control arms.
6. Disconnect front center frame mount bushing brackets. **(Note orientation of bracket and bar before removing the bar.)**



7. Remove sway bar from the vehicle.

## **EIBACH FRONT BAR INSTALLATION**

1. Apply supplied lubricant to new sway bar bushings.
2. Install new Eibach sway bar in reverse order of removal.