

Installation Instructions

Eibach Springs, Inc. • 264 Mariah Circle • Corona, California 92879-1751 • USA • Tech Support 800-222-8811 Ext 114

Anti-Roll-Kit # 4031.312

2006-2013 Honda Civic, All, Exc. Hybrid 2013-14 Acura ILX, 2.4L 4 Cyl.

Kit Contents	Description	Part Number	Qty	
	Rear Bar	4031.320R	1	
	Anti-Roll Hardware Kit	4031.312HK	1	
	Instructions	4031.312INST	1	

NOTES: Read All Instructions Before Beginning Installation

- Only qualified mechanics experienced in the installation and removal of suspension components should perform this installation.
- Use of a hoist and screw jack is highly recommended and will substantially reduce installation time.
- **Installation time:** Is approximate .5 hour with the use of a hoist.
- Never work on or under a vehicle unless it is properly supported.
- Tire Rotation: In order to increase the life of your tires, it is recommended to rotate your tires every 3,000 miles.

FACTORY REAR BAR REMOVAL



Photo 1

 Begin by removing rear OE end link assembly from both ends of the factory bar. Note: The end links will be reused to install the new Eibach rear bar.



Photo 2

- Next remove the frame mount bushing brackets securing the bar to the vehicle. Note: The brackets will be re-used to install the new Eibach rear bar.
- Now remove the rear bar from the vehicle. Note: Be sure to take note of the orientation of the rear bar as the Eibach bar will be installed in the same orientation.

EIBACH REAR BAR INSTALLATION



- Apply some poly lubricant to the inside of the new rear bushings.
- 2. Installed the new bushings on the Eibach bar.



Photo 3

3. Install the new Eibach rear bar using the stock bushings brackets. (See Photo 3)



Photo 4

- 4. Secure the OE end links to the new Eibach bar using the OE nuts. (See Photo 4)
- 5. Double check to make sure everything is properly tightened and positioned before driving the vehicle.