
## Installation Instructions





## *Sportline* # 4.9563

2009+ Nissan Cube, 1.8L

Kit Contents	Description	Part Number	Qty	
	Front Spring	4.9563F	2	
	Rear Spring	4.9563R	2	
	Front Bump Stop	BS770052	2	
	Front Dust Boot	BS770043	2	
	Information Kit	EPAK	1	
	Instructions	4.9563INST	1	

## NOTES: Read All Instructions Before Beginning Installation

- Only qualified mechanics experienced in the installation and removal of suspension components should perform this installation.
- Use of a hoist is highly recommended and will substantially reduce installation time.
- Never work on or under a vehicle unless it is properly supported by safety stands and wheels are blocked.
- **Sportline** springs are marked with an F, for Front and R, for the Rear.
- **Sportline** springs should be installed with the Eibach Logo right side up. All original stock spring isolators, dampers and tubing should be retained from the stock springs and used when installing the **Sportline** Springs.
- After installation, it is always important to inspect and adjust the following if necessary:
  - Wheel alignment such as camber, caster & toe
  - Tire and/or wheel fender clearance, when aftermarket tires and wheels are used.
  - Brake line clearance and attachments
  - Brake anti-locking and anti-skid system sensors
- Tire Rotation: In order to increase the life of your tires, it is recommended to rotate your tires every 3,000 miles.
- For MacPherson type front suspension, it is important to mark the orientation of the upper perch with respect to the lower perch before disassembly. This orientation must remain the same with the installation of the Pro Kit springs. Noise may result if this procedure is not performed correctly

## **ALIGNMENT:**

After installation, it will be necessary to perform a full vehicle alignment. Eibach offers the following alignment kits for this vehicle.

