

## Installation Instructions

Eibach Springs, Inc. • 264 Mariah Circle • Corona, California 92879-1751 • USA • Tech Support 800-222-8811 Ext 114

## Pro-Damper - # 3561.8001SB

Contents	Description	Part Number	Qty	
	Damper Assy.	3561.8001.1	1	
	Washer, 5/16"	H50026200	2	
	Nut, 5/16'-18	H63021600	2	
	Body Bushing	84-1263	1	
	Stem Bushing	84-1242	4	
	Bar Pin	84-1608	1	
	Rod End Assy.	28-1651	1	
	Information Kit	EPAK	1	
	Installation Instructions	3561.8001INST	1	



## NOTES: Read All Instructions Before Beginning Installation

- 1. Park vehicle on level surface and set emergency brake. Raise and support the vehicle with safety stands. Refer to factory manual for proper location of safety stands.
- 2. Power washing your chassis will make the installation cleaner.
  - **NOTE**: Never work on or under a vehicle unless it is properly supported by safety stands.
- 3. Loosen and remove the OE shock per the factory recommended removal procedure.
- 4. Installation of the Eibach Pro Damper shock should be done in the reverse order of removal.