

Installation Instructions

Eibach Springs, Inc. • 264 Mariah Circle • Corona, California 92879-1751 • USA • Tech Support 800-222-8811 Ext 114

PRO-LIFT # E30-35-034-01-20

2017-19 Ford F250, Super Duty, 4WD 2017-19 Ford F350, Super Duty, 4WD

Note: The Pro Truck Leveling springs must not be used with the OE shocks. Extended travel dampers are required to avoid damage to the suspension.

Note: Installation of the extended travel dampers requires extended length brake lines, stabilizer bar spacers and an extended vacuum line which are not included in this kit.

Warning: Do not attempt to install the springs and/or drive the truck if any of the above mentioned additional parts are missing as damage to the truck as well as personal injury can occur.

Kit Contents	Description	Part Number	Qty	
	Front Spring	F31-35-034-01-FA	2	
	Instructions	E30-35-034-01-20INST	1	

NOTES: Read All Instructions Before Beginning Installation

- Only qualified mechanics experienced in the installation and removal of suspension components should perform this installation.
- **Use** of a hoist is highly recommended and will substantially reduce installation time.
- Never work on or under a vehicle unless it is properly supported by safety stands and wheels are blocked.
- Never use impact wrenches or impact guns to install or remove shock absorber piston components, shafts and piston rod nuts.
- **PRO-LIFT** springs should be installed with the Eibach Logo right side up. All original stock spring isolators, dampers and tubing should be retained from the stock springs and used when installing the **PRO-LIFT** Springs.
 - After installation, it is always important to inspect and adjust the following if necessary:
 - Wheel alignment such as camber, caster & toe
 - Tire and/or wheel fender clearance, when aftermarket tires and wheels are used.
 - Brake line clearance and attachments
 - Brake anti-locking and anti-skid system sensors
- **Tire Rotation:** In order to increase the life of your tires, it is recommended to rotate your tires every 3,000 miles.

Additional *Eibach* Components Available For Your Truck

Eibach Kits	Part Number	Description	Front	Rear
Pro Truck Sport front dampers	E60-35-034-01-10	Off-Road Performance	N/A	N/A
Pro Truck Sport rear dampers	E60-35-034-01-01	Off-Road Performance	N/A	N/A

No bump stop modifications required