



# Installation Instructions

Eibach Springs, Inc. • 264 Mariah Circle • Corona, California 92879-1751 • USA • Tech Support 800-222-8811 Ext 114

## PRO-LIFT # E30-82-072-04-02

### 2008-19 Toyota Land Cruiser, 4wd, J200

**Note: The Pro Truck Lift springs must not be used with the OE shocks. Extended travel shocks are required to avoid damage to the suspension.**

Kit Contents	Description	Part Number	Qty
	Rear Spring, HD	F31-82-072-04-RA	2
	Instructions	E30-82-072-04-02INST	1

#### NOTES: Read All Instructions Before Beginning Installation

- Only qualified mechanics experienced in the installation and removal of suspension components should perform this installation.
- Use of a hoist is highly recommended and will substantially reduce installation time.
- Never work on or under a vehicle unless it is properly supported by safety stands and wheels are blocked.
- Never use impact wrenches or impact guns to install or remove shock absorber piston components, shafts and piston rod nuts.
- **PRO-LIFT** springs should be installed with the Eibach Logo right side up. All original stock spring isolators, dampers and tubing should be retained from the stock springs and used when installing the **PRO-LIFT** Springs.
- After installation, it is always important to inspect and adjust the following if necessary:
  - Wheel alignment such as camber, caster & toe
  - Tire and/or wheel fender clearance, when aftermarket tires and wheels are used.
  - Brake line clearance and attachments
  - Brake anti-locking and anti-skid system sensors
- **Tire Rotation:** In order to increase the life of your tires, it is recommended to rotate your tires every 3,000 miles.
- For MacPherson Strut type front suspension, it is important to mark the orientation of the upper perch with respect to the lower perch before disassembly. This orientation must remain the same with the installation of the Pro Kit springs. Noise may result if this procedure is not performed correctly.

#### Additional Eibach Components Available For Your Truck

Eibach Kits	Part Number	Description	Front	Rear
<b>Pro Truck Sport Leveling front dampers</b>	E60-82-072-03-10	Off-Road Performance	+0-2.5"	N/A
<b>Pro Truck Sport Leveling rear dampers</b>	E60-82-072-03-01	Off-Road Performance	N/A	0-1"

Rear lift heights shown below are based on 0-400 lbs of additional weight and are an approximation, your heights may vary depending on the placement of the additional weight.

Weight	Lift	Weight	Lift	Weight	Lift
0 lbs	1.6"	200 lbs	1.2"	400 lbs	0.8"
100 lbs	1.4"	300 lbs	1.0"		