

# Installation Instructions

Eibach Inc .264 Mariah Circle Corona, CA 92879 USA Tech Support 800-507-2338 ext. 114



## Pro Lift Kit: E30-82-073-02-02

### Kit Contents

| Description                    | Part Number      | Quantity |
|--------------------------------|------------------|----------|
| HD Rear Spring                 | F31-82-073-02-RA | 2        |
| Instructions                   | D3930            | 1        |
| Eibach Decal/Instruction Sheet | 990637           | 1        |

### Notes

#### Read all instructions before beginning installation

- Only qualified mechanics experienced in the installation and removal of suspension components should perform this installation.
- Use of a hoist and screw jack is highly recommended and will substantially reduce installation time.
- Never work on or under a vehicle unless it is properly supported or wheels are blocked.
- Never use impact wrenches or impact guns to install or remove shock absorber piston components, shafts and Piston rod nuts.
- For MacPherson Strut type suspension, it is important to mark the orientation of the upper mount with respect to the lower spring perch before disassembly. This must remain the same with the orientation of the Pro-Kit Springs. Noise may result from incorrect procedure.
- All Eibach springs should be installed with the Eibach logo right-side-up. All original stock spring isolators and dampers should be retained from the stock springs when installing Eibach springs.
- After Installation, inspect and adjust the following: Wheel Alignment; tire/wheel fender clearance when using aftermarket wheels or tires; brake line clearance and attachments; anti-lock-brake system sensors

### Loaded Heights

| WEIGHT | LIFT  |
|--------|-------|
| 0LBS   | 2.00" |
| 100LBS | 1.75" |
| 200LBS | 1.50" |
| 300LBS | 1.25" |
| 400LBS | 1.00" |

Approximate lift heights based on the above listed loads, lift heights will vary based upon load distribution on vehicle.