Eibach Inc. 264 Mariah Circle Corona, CA 92879 USA Tech Support 800-507-2338 ext. 114



## E30-35-063-02-22

22+ Ford Bronco Raptor

Notes

The Pro Truck Leveling springs must be used with the OE shocks.

Front Spring       F31-35-060-02-FA         Rear Spring       F31-35-063-02-RA         Installation Notes       Read all instructions before beginning installation         • Only qualified mechanics experienced in the installation and removal of susper components should perform this installation.       • Use of a hoist and screw jack is highly recommended and will substantially red installation time.         • Never work on or under a vehicle unless it is properly supported by safety stanwheels are blocked.       • Never use impact wrenches or impact guns to install or remove shock absorbe components, shafts and Piston rod nuts.         • All Eibach springs should be installed with the Eibach logo right-side-up. All origistok spring isolators and dampers should be retained from the stock springs winstalling Eibach springs.         • After Installation, inspect and adjust the following: Wheel Alignment; tire/wheel clearance when using aftermarket wheels or tires; brake line clearance and attachments; anti-lock-brake system sensors.         • Tire Rotation: In order to increase the life of your tires, it is recommended to rot tires every 3,000 miles.         • For MacPherson Strut type front suspension, it is important to mark the orientat the upper perch with respect to the lower perch before disassembly. This orient	Quantity	lumber	Part Nu	Description	Kit Contents
Installation Notes         Read all instructions before beginning installation           9         Only qualified mechanics experienced in the installation and removal of susper components should perform this installation.           9         Use of a hoist and screw jack is highly recommended and will substantially red installation time.           9         Never work on or under a vehicle unless it is properly supported by safety stan- wheels are blocked.           9         Never use impact wrenches or impact guns to install or remove shock absorbe components, shafts and Piston rod nuts.           9         All Eibach springs should be installed with the Eibach logo right-side-up. All orig stock spring isolators and dampers should be retained from the stock springs w installing Eibach springs.           9         After Installation, inspect and adjust the following: Wheel Alignment; tire/wheel clearance when using aftermarket wheels or tires; brake line clearance and attachments; anti-lock-brake system sensors.           9         Tire Rotation: In order to increase the life of your tires, it is recommended to rol tires every 3,000 miles.           9         For MacPherson Strut type front suspension, it is important to mark the orientar the upper perch with respect to the lower perch before disassembly. This orient	2	5-060-02-FA	F31-35-0	Front Spring	
<ul> <li>Notes</li> <li>Only qualified mechanics experienced in the installation and removal of susper components should perform this installation.</li> <li>Use of a hoist and screw jack is highly recommended and will substantially red installation time.</li> <li>Never work on or under a vehicle unless it is properly supported by safety stand wheels are blocked.</li> <li>Never use impact wrenches or impact guns to install or remove shock absorbed components, shafts and Piston rod nuts.</li> <li>All Eibach springs should be installed with the Eibach logo right-side-up. All originates the stock spring isolators and dampers should be retained from the stock springs winstalling Eibach springs.</li> <li>After Installation, inspect and adjust the following: Wheel Alignment; tire/wheel clearance when using aftermarket wheels or tires; brake line clearance and attachments; anti-lock-brake system sensors.</li> <li>Tire Rotation: In order to increase the life of your tires, it is recommended to rot tires every 3,000 miles.</li> <li>For MacPherson Strut type front suspension, it is important to mark the orientat the upper perch with respect to the lower perch before disassembly. This oriented to the lower perch before disastembly. This oriented to the lower perch before disastembly.</li> </ul>	2	i-063-02-RA	F31-35-0	Rear Spring	
must remain the same with the installation of the springs. Noise may result if th procedure is not performed correctly.	uce ds and r piston ginal vhen fender tate your tion of tation	e installation and removal of suspen mmended and will substantially redu s properly supported by safety stand to install or remove shock absorber he Eibach logo right-side-up. All origo be retained from the stock springs w owing: Wheel Alignment; tire/wheel for tires; brake line clearance and rs. f your tires, it is recommended to rotant n, it is important to mark the orientatt erch before disassembly. This orient	chanics experienced in the is Id perform this installation. I screw jack is highly recome under a vehicle unless it is ed. wrenches or impact guns to ts and Piston rod nuts. should be installed with the cors and dampers should be oprings. nspect and adjust the follow sing aftermarket wheels or lock-brake system sensors. rder to increase the life of y miles. Strut type front suspension, ith respect to the lower performance with the installation of	<ul> <li>Only qualified mech components should</li> <li>Use of a hoist and s installation time.</li> <li>Never work on or u wheels are blocked</li> <li>Never use impact w components, shafts</li> <li>All Eibach springs s stock spring isolato installing Eibach sp</li> <li>After Installation, in clearance when usi attachments; anti-lo</li> <li>Tire Rotation: In ord tires every 3,000 m</li> <li>For MacPherson St the upper perch wit must remain the sa</li> </ul>	
Additional Eibach Components for your VehicleEibach KitsPart NumberDescriptionFront	Rear	Description Front	Part Number	Eibach Kits	Components for