

# Installation Instructions

Eibach Springs, Inc. • 264 Mariah Circle • Corona, California 92879-1751 • USA • Tech Support 800-222-8811 Ext 114



## SPORTLINE # 4.6463

Nissan, 350Z, Incl. Roadster 2003 & Up

Kit Contents	Description	Part Number	Qty
	Front Spring	4.6463F	2
	Rear Spring	4.6463R	2
	Information Kit	EPACK	1
	Instructions	4.6463INST	1

### NOTES: Read All Instructions Before Beginning Installation

- Only qualified mechanics experienced in the installation and removal of suspension components should perform this installation.
- Use of a hoist is highly recommended and will substantially reduce installation time.
- Never work on or under a vehicle unless it is properly supported by safety stands.
- **SPORTLINE** springs are marked with an F, for Front and an R, for the Rear.
- **SPORTLINE** springs should be installed with the **Eibach** Logo right side up. All original stock spring isolators, dampers and tubing should be retained from the stock springs and used when installing the springs.
- After installation, it is always important to inspect and adjust the following if necessary:
  - Wheel alignment such as camber, caster & toe
  - Tire and/or wheel fender clearance, when aftermarket tires and wheels are used.
  - Brake line clearance and attachments
  - Brake anti-locking and anti-skid system sensors

**Tire Rotation:** In order to increase the life of your tires, it is recommended to rotate your tires every 3,000 miles.

After installation, it will be necessary to perform a full vehicle alignment.

### Additional Eibach Components Available For Your Car

Eibach Kits	Part Number	Description	Front	Rear
<b>Anti-Roll Kit</b>	6364.320	Performance Tuned Handling	34.0 mm	27.0 mm

### Bump Stop Trimming Instructions

Typical Bump-Stop  
(Bump-Stop from your vehicle may have different shape)

