

Installation Instructions

Eibach Springs, Inc. • 264 Mariah Circle • Corona, California 92879-1751 • USA • Tech Support 800-222-8811 Ext 114



Anti-Roll-Kit # 2873.310

2005-2006 Dodge Magnum, Dodge Charger, Chrysler 300

Kit Contents	Description	Part Number	Qty
	Front Bar	2873.320F	1
	Anti-Roll Hardware Kit	2873.310HK	1
	Front bushings	UB0109	2
	Information Kit	EPAK	1
	Instructions	2873.310INST	1

NOTES: Read All Instructions Before Beginning Installation

- **Only qualified mechanics experienced in the installation and removal of suspension components should perform this installation.**
- **Use** of a hoist and screw jack is highly recommended and will substantially reduce installation time.
- **Installation time:** Is approximately .5 hours with the use of a hoist.
- **Never work on or under a vehicle unless it is properly supported.**
- **Tire Rotation:** In order to increase the life of your tires, it is recommended to rotate your tires every 3,000 miles.

Additional Eibach Components Available For Your Car

Eibach Kits	Part Number	Description	Front	Rear
<i>Pro-Kit</i>	2873.140	High Performance Handling	1.6 In.	1.6 In.
<i>Sport line</i>	4.7328	High Performance Handling	2.0 In.	2.0 In.

FACTORY FRONT BAR REMOVAL

1. With the vehicle safely supported, remove all 4 wheels.
2. Remove the two aluminum heat shields that cover the sway bar mounting brackets.
3. Remove sway bar mounting brackets.
4. Remove the two nuts that secure the sway bar to the end links, and then remove the sway bar.

EIBACH FRONT BAR INSTALLATION

1. Locate the two new front bushings (Part# UB0109) and apply the supplied lubricant to the inside of the new bushings. Install the bushings on to the new Eibach Front bar with the "cut" portion toward the rear of the vehicle.
2. Complete the installation of the new Eibach Front Anti-Roll bar in the reverse order of removal using the factory bushing brackets and other factory hardware.