

Installation Instructions



Eibach Springs, Inc. • 264 Mariah Circle • Corona, California 92879-1751 • USA • Tech Support 800-222-8811 Ext 114

Pro-Kit # 6041.140

2003-2005 Evo VIII

2006 Evo IX, (Incl. GSR, RS & MR)

Kit Contents	Description	Part Number	Qty
	Front Spring	116000501VA	2
	Rear Spring	116000501HA	2
	Information Kit	EPAK	1
	Instructions	6041.140INST	1

NOTES: Read All Instructions Before Beginning Installation

- **Only qualified mechanics experienced in the installation and removal of suspension components should perform this installation.**
- **Use** of a hoist is highly recommended and will substantially reduce installation time.
- **Never work on or under a vehicle unless it is properly supported by safety stands.**
- **PRO-KIT** springs in this kit are marked with a VA, for Front and HA, for the Rear.
- **PRO-KIT** springs should be installed with the Eibach Logo right side up. All original stock spring isolators, dampers and tubing should be retained from the stock springs and used when installing the **PRO-KIT** Springs.
- **After** installation, it is always important to inspect and adjust the following if necessary:
 - Wheel alignment such as camber, caster & toe
 - Tire and/or wheel fender clearance, when aftermarket tires and wheels are used.
 - Brake line clearance and attachments
 - Brake anti-locking and anti-skid system sensors

Tire Rotation: In order to increase the life of your tires, it is recommended to rotate your tires every 3,000 miles.

After installation, it will be necessary to perform a full vehicle alignment.

NO BUMP STOP TRIMMING REQUIRED ON THIS VEHICLE.

