

Installation Instructions

Eibach Springs, Inc. 264 Mariah Circle Corona, California 92879-1751 USA- Tech Support 800-222-8811 Ext 114



PRO-KIT - # 6376.140

2006 Infiniti M45 and M35 Exc. AWD

Kit Contents	Description	Part Number	Qty
	Front Spring	6376.001	2
	Rear Spring	6376.002	2
	Information Kit	EPAK	1
	Instructions	6376.140INST	1

NOTES: **Read All Instructions Before Beginning Installation**

- Installation of a **PRO-KIT** Spring set should only be performed by a qualified mechanic experienced in the installation and removal of suspension springs.
- Use of a hoist is highly recommended and will substantially reduce installation time.
- **Never work on or under a vehicle unless it is properly supported by safety stands and wheels are blocked.**
- **PRO-KIT** Springs are marked with 001 and 002 (located at the end of the part number) designating front and rear spring respectively.
- **PRO-KIT** Springs should be installed with the **Eibach** Logo right side up. All original stock spring isolators, dampers and tubing should be retained from the stock springs and reused
- **After** installation, it is always important to inspect and adjust the following if necessary:
 - Wheel alignment such as camber, caster & toe
 - Tire and/or wheel fender clearance
 - Brake line clearance and attachments
 - Brake anti-locking and anti-skid system sensors
- **Tire Rotation:** To increase the life of your tires, it is recommended to rotate your tires every 3,000 miles.

Alignment:

- After installation, it will be necessary to perform a full vehicle alignment using factory specifications.:

Bump Stop Trimming Instructions

No bumpstop trim needed.

