

# Installation Instructions

Eibach Springs, Inc. • 264 Mariah Circle • Corona, California 92879-1751 • USA • Tech Support 800-222-8811 Ext 114

## Pro-Damper – # 3561.8002

Contents	Description	Part Number	Qty
	Damper Assy.	3561.8002.1	1
	Dust Boot	E72-X006C02	1
	Cup Washer	84-1756CZ	4
	Hat Bushing	84-1359	4
	Nylock Nut, M10-1.5	H63074700	2
	Spacer	8000231	1
	Information Kit	EPAK	1
	Installation Instructions	3561.8002INST	1



### NOTES: Read All Instructions Before Beginning Installation

1. Park vehicle on level surface and set emergency brake. Raise and support the vehicle with safety stands. Refer to factory manual for proper location of safety stands.
2. Power washing your chassis will make the installation cleaner.
  - **NOTE:** Never work on or under a vehicle unless it is properly supported by safety stands.
3. Loosen and remove the OE shock per the factory recommended removal procedure.
4. Installation of the Eibach Pro Damper shock should be done in the reverse order of removal.