

Installation Instructions

Eibach Springs, Inc. • 264 Mariah Circle • Corona, California 92879-1751 • USA • Tech Support 800-222-8811 Ext 114



Pro-Kit # 6364.140

Nissan, 350Z, Incl. Roadster 2003 & Up

| Kit Contents | Description | Part Number | Qty |
|--------------|-----------------|--------------|-----|
| | Front Spring | 6364.001 | 2 |
| | Rear Spring | 6364.002 | 2 |
| | Information Kit | EPACK | 1 |
| | Instructions | 6364.140INST | 1 |

NOTES: Read All Instructions Before Beginning Installation

- Only qualified mechanics experienced in the installation and removal of suspension components should perform this installation.
- Use of a hoist is highly recommended and will substantially reduce installation time.
- Never work on or under a vehicle unless it is properly supported by safety stands.
- **PRO-KIT** springs are marked with a .001, for Front and .002, for the Rear.
- **PRO-KIT** springs should be installed with the **Eibach** Logo right side up. All original stock spring isolators, dampers and tubing should be retained from the stock springs and used when installing the **PRO-KIT** Springs.
- After installation, it is always important to inspect and adjust the following if necessary:
 - Wheel alignment such as camber, caster & toe
 - Tire and/or wheel fender clearance, when aftermarket tires and wheels are used.
 - Brake line clearance and attachments
 - Brake anti-locking and anti-skid system sensors

Tire Rotation: In order to increase the life of your tires, it is recommended to rotate your tires every 3,000 miles.

After installation, it will be necessary to perform a full vehicle alignment.

Additional Eibach Components Available For Your Car

| Eibach Kits | Part Number | Description | Front | Rear |
|----------------------|-------------|----------------------------|---------|---------|
| Anti-Roll Kit | 6364.320 | Performance Tuned Handling | 34.0 mm | 27.0 mm |

Bump Stop Trimming Instructions

Typical Bump-Stop
(Bump-Stop from your vehicle may have different shape)

