

Installation Instructions

Eibach Springs, Inc. • 264 Mariah Circle • Corona, California 92879-1751 • USA • Tech Support 800-222-8811 Ext 114

Adapter Kit # 5.1010K

For use with Caster Camber plates and Pro Street S Coilovers

Kit Contents	Description	Part Number	Qty
	Bearing Plate	8001045	2
	Flanged Sleeve	UB0037	2
	Instructions	5.1010KINST	1

NOTES: Read All Instructions Before Beginning Installation

- Only qualified mechanics experienced in the installation and removal of suspension components should perform this installation.
- Use of a hoist and screw jack is highly recommended and will substantially reduce installation time.
- Never work on or under a vehicle unless it is properly supported.

Adapter installation for Camber Plates



Photo 1

1. Remove the upper bearing plate from the Pro Street S upper bearing assembly. (See Photo 1)



Photo 2



Photo 3

2. Install the provided upper bearing plate adapter as shown. The adapter must fully slide over the shoulder below the threads as shown in the picture. (See Photos 2 & 3)



Photo 4



Photo 5

3. Install the flanged sleeve as shown. **(See Photos 4 & 5)**
4. Double check to make sure everything is properly positioned, then, install the coilover assembly into the car per the caster camber plate instructions.