

Installation Instructions

Eibach Springs, Inc. • 264 Mariah Circle • Corona, California 92879-1751 • USA • Tech Support 800-222-8811 Ext 114



Anti-Roll-Kit # 3882.312

Chevrolet/GMC/Cadillac Full Size SUV's (GMT800/GMT900 chassis)

Including vehicles with autoride (See applications listing for specific model years)

Kit Contents	Description	Part Number	Qty
	Rear Bar	3882.320R	1
	Anti-Roll Hardware Kit	3882.312HK	1
	Information Kit	EPAK	1
	Instructions	3882.312INST	1

NOTES: Read All Instructions Before Beginning Installation

- **Only qualified mechanics experienced in the installation and removal of suspension components should perform this installation.**
- **Use** of a hoist and screw jack is highly recommended and will substantially reduce installation time.
- **Installation time:** Is approximate .5 hour with the use of a hoist.
- **Never work on or under a vehicle unless it is properly supported.**
- **Tire Rotation:** In order to increase the life of your tires, it is recommended to rotate your tires every 3,000 miles.

Additional Eibach Components Available For Your SUV

Eibach Kits	Part Number	Description /	Front	Rear
<i>Air-Ride Equipped</i>	38106.540	High Performance Handling	1.8"-2.5"	2.4"-2.6"
<i>Non Air-Ride Equipped</i>	38107.540	High Performance Handling	1.8"	2.4"

FACTORY REAR BAR REMOVAL

1. Begin by disconnecting the OE end links from both ends of the rear bar. Note: The end links will be re-used to install the new Eibach rear bar
2. Next remove the frame mount bushing brackets securing the bar to the rear axle. Note: The brackets will be re-used to install the new Eibach rear bar.
3. Now remove the rear bar.
4. order of disassembly.

EIBACH REAR BAR INSTALLATION

1. Apply some poly lubricant to the inside of the new rear bushings and install both bushings on the bar.
2. Installation of the new Eibach rear bar is the reverse order of disassembly.