

Installation Instructions

Eibach Springs, Inc. • 264 Mariah Circle • Corona, California 92879-1751 • USA • Tech Support 800-222-8811 Ext 114



Anti-Roll-Kit # 38106.310

Chevrolet, Tahoe, Suburban, Avalanche, 2WD/4WD, 2007

GMC, Yukon, Yukon XL, Denali, 2WD/4WD, 2007

Cadillac, Escalade, Escalade EXT, ESV, 2007

Kit Contents	Description	Part Number	Qty
	Front Bar	38106.320F	1
	Anti-Roll Hardware Kit	38106.310HK	1
	Information Kit	EPAK	1
	Instructions	38106.310INST	1

NOTES: Read All Instructions Before Beginning Installation

- **Only qualified mechanics experienced in the installation and removal of suspension components should perform this installation.**
- **Use** of a hoist and screw jack is highly recommended and will substantially reduce installation time.
- **Installation time:** Is approximate .5 hour with the use of a hoist.
- **Never work on or under a vehicle unless it is properly supported.**
- **Tire Rotation:** In order to increase the life of your tires, it is recommended to rotate your tires every 3,000 miles.

Additional Eibach Components Available For Your SUV

Eibach Kits	Part Number	Description /	Front	Rear
<i>Air-Ride Equipped</i>	38106.540	High Performance Handling	1.8"-2.5"	2.4"-2.6"
<i>Non Air-Ride Equipped</i>	38107.540	High Performance Handling	1.8"	2.4"

FACTORY FRONT BAR REMOVAL

1. Begin by removing front OE end link assembly from both ends of the factory bar. Note: The end links will be re-used to install the new Eibach front bar.
2. Next remove the frame mount bushing brackets securing the bar to the vehicle. Note: The brackets will be re-used to install the new Eibach front bar.
3. Now remove the front bar from the vehicle.

EIBACH FRONT BAR INSTALLATION

1. Apply some poly lubricant to the inside of the new front bushings.
2. Installed the new bushings on the Eibach bar.
3. Installation of the new Eibach front bar is the reverse order of disassembly.