

# Installation Instructions

Eibach Springs, Inc. • 264 Mariah Circle • Corona, California 92879-1751 • USA • Tech Support 800-222-8811 Ext 114

## *Pro-Damper Kit – # 38144.840*

2010-11 Chevrolet Camaro SS, Coupe, 6.2L V8

2010-12 Chevrolet Camaro, Coupe, 3.6L V6

<b>Kit Contents</b>	<b>Description</b>	<b>Part Number</b>	<b>Qty</b>
	Front Damper, Right	38144.8001R	1
	Front Damper, Left	38144.8001L	1
	Rear Damper	38144.8002	2
	Information Kit	EPAK	1

### **NOTES: Read All Instructions Before Beginning Installation**

1. Park vehicle on level surface and set emergency brake. Raise and support the vehicle with safety stands. Refer to factory manual for proper location of safety stands.
2. Power washing your chassis will make the installation cleaner.
  - **NOTE:** Never work on or under a vehicle unless it is properly supported by safety stands.
  - Be sure to follow the factory manual for the correct removal and installation procedures as well as torque specifications.

### **Additional Eibach Components Available For Your Cars**

<b>Eibach Kits</b>	<b>Part Number</b>	<b>Description /</b>	<b>Front</b>	<b>Rear</b>
<i>Pro-Kit</i>	38144.140	Performance Handling	"Call"	"Call"
<i>Pro Street Coilovers</i>	38144.711	Performance Handling	"Call"	"Call"
<i>Anti-Roll Kit</i>	38144.320	Performance Handling	29mm	29mm

OR

Check Out Our Application Guide On-Line at <http://www.eibach.com>