

# Installation Instructions

Eibach Springs, Inc. • 264 Mariah Circle • Corona, California 92879-1751 • USA • Tech Support 800-222-8811 Ext 114



## Anti-Roll-Kit # 4043.310

2000-2009 Honda S2000

Kit Contents	Description	Part Number	Qty
	Front Bar	4043.320F	1
	Anti-Roll Hardware Kit	4043.310HK	1
	Front Bushing	UB0263	2
	Information Kit	EPAK	1
	Instructions	4043.310INST	1

### NOTES: Read All Instructions Before Beginning Installation

- Only qualified mechanics experienced in the installation and removal of suspension components should perform this installation.
- Use of a hoist and screw jack is highly recommended and will substantially reduce installation time.
- **Installation time:** Is approximate .5 hour with the use of a hoist.
- **Never work on or under a vehicle unless it is properly supported.**
- **Tire Rotation:** In order to increase the life of your tires, it is recommended to rotate your tires every 3,000 miles.

### FACTORY FRONT BAR REMOVAL

1. Raise the vehicle off the ground and firmly support it with safety stands. **Note: Never work on or under a vehicle that isn't properly supported with the appropriate safety equipment.**



Photo 1

2. Remove the plastic cover from the underside of the vehicle. (See Photo 1)



Photo 2

3. Loosen and remove the nuts that secure the end links to the ends of the OE anti-roll bar. (See Photo 2)



**Photo 3**

4. Loosen and remove the bolts that secure the OE bushing brackets to the subframe. **(See Photo 3)**
5. You can now remove the bar from the vehicle. **Note: Be sure to note the orientation of the OE bar as the Eibach bar will be installed in the same orientation.**

### **EIBACH FRONT BAR INSTALLATION**

1. Apply some poly lubricant to the inside of the new front bushings.
2. Installed the new bushings onto the Eibach bar.




**Photo 4**

3. Install the new Eibach front bar into the vehicle and secure the bar to the vehicle using the OE bushing brackets, and bolts. **(See Photo 4)**



**Photo 5**

4. Secure the end links to the Eibach front bar using the OE nuts. **(See Photo 5)**
5. Double check to make sure everything is properly positioned, then, tighten all hardware.
6. Reinstall the plastic cover to the underside of the vehicle.



### **FRONT**

- a) Softest Setting.
  - **Reduces** under-steer
  - Use in rain or on slick roads.
  - Use on rough or bumpy roads.
  - Increases comfort.
- b) Firmest Setting.
  - **Reduces** over-steer
  - Use on dry roads and tracks.
  - Use on smooth roads and tracks.
  - Do not use on wet or slick roads.