

# Installation Instructions

Eibach Springs, Inc. • 264 Mariah Circle • Corona, California 92879-1751 • USA • Tech Support 800-222-8811 Ext 114



## *Pro-Truck*: 38110.520 (Front Springs Only)

2007 Chevrolet Silverado Regular Cab (GMT900)

2007 Chevrolet Silverado Ext Cab (GMT900)

2007 Chevrolet Silverado Crew Cab (GMT900)

Kit Contents	Description	Part Number	Qty
	Front Spring	38129.001	2
	Front Bump Stop	BS770015	2
	Information Kit	EPAK	1
	Instructions	38110.520INST	1

### NOTES: **Read All Instructions Before Beginning Installation**

- Installation of a *Pro-Kit* set should only be performed by a qualified mechanic experienced in the installation and removal of suspension springs.
- Use of a hoist is highly recommended and will substantially reduce installation time.
- **Never work on or under a vehicle unless it is properly supported by safety stands and wheels are blocked.**
- *Pro-Kit* Springs are marked with an **001** and an **002** (located at the end of the part number) designating front and rear springs.
- *Pro-Kit* Springs should be installed with the **Eibach** Logo right side up. All original stock spring isolators, dampers and tubing should be retained from the stock springs and used when installing the *Pro-Kit* Springs.
- **After** installation, it is always important to inspect and adjust the following if necessary:
  - Wheel alignment such as camber, caster & toe.
  - Tire and/or wheel fender clearance.
  - Brake line clearance and attachments.
  - Brake anti-locking and anti-skid system sensors.
- **Tire Rotation:** In order to increase the life of your tires, it is recommended to rotate your tires every 3,000 miles.


**ALIGNMENT:** After installation, it will be necessary to perform a full vehicle alignment using factory specifications.

**Note:** During installation of the Eibach rear springs it is extremely important that all bushing related pivot points be re-torqued with the full weight of the vehicle on the suspension, this is done to prevent "bushing pre-load". This is easiest with the vehicle on a drive on type of hoist. If this is not done, bushing damage and un-even lowering may result.

### Bump Stop Trimming Instructions

Typical Bump-Stop  
(Bump-Stop from your vehicle may have different shape)

Front Bump Stop:  
*Replace with Bump stop provided  
In the kit.  
(P/N BS770015)*



Rear Bump Stop Trim:  
*No Trimming Required*