

# Installation Instructions

Eibach Springs, Inc. • 264 Mariah Circle • Corona, California 92879-1751 • USA • Tech Support 800-222-8811 Ext 114

## Anti-Roll-Kit # AK41-209-003-01-01

Kit Contents	Description	Part Number	Qty
	Rear Bracket, Left	UB0112L.1	1
	Rear Bracket, Right	UB0112R.1	1
	Bolt, Carriage	H33025071	4
	Washer, 8mm	H46025000	4
	Instructions	AK41-209-003-01-01INST	1

### NOTES: Read All Instructions Before Beginning Installation

- Only qualified mechanics experienced in the installation and removal of suspension components should perform this installation.
- Use of a hoist and screw jack is highly recommended and will substantially reduce installation time.
- Never work on or under a vehicle unless it is properly supported.

### FACTORY REAR BAR REMOVAL



Photo 1

1. Loosen and remove the hardware that secures the end link to the end of the anti roll bar. (See Photo 1)




Photo 2

2. Loosen and remove the OE hardware that secures the engine mount to the frame. (See Photo 2)




Photo 3




Photo 4

3. Loosen and remove the hardware that secures the bushing bracket to the frame as shown. (See Photos 3 & 4)



Photo 5



Photo 6

4. You can now slide the reinforcement bracket over the bar lining up the holes on the bracket with the bolts on the engine mount and frame. **Note: Do not tighten the hardware at this time.** (See Photos 5 & 6)



Photo 7



Photo 8

5. Reinstall and secure the OE bushing bracket with the provided carriage bolts and OE nuts as shown. (See Photos 7 & 8)




Photo 9






Photo 10

6. You can now secure the engine mount and bracket with the provided washers and OE nuts as shown. (See Photos 9 & 10)



**Photo 11**

7. Secure the end link to the end of the bar as shown.  
**(See Photo 11)**
8. Repeat this process on the opposite side.



9. Double check to make sure everything is properly positioned and tightened, then, road test the vehicle.
10. After road testing, double check all hardware to make sure everything is properly tightened and re-tighten if necessary.